

Preamble

These instructions will guide you through installation of the Mini Motion Package onto the appropriate piece of UTV equipment

Tools and Equipment Required

No tools are required other than a pair of side cutters or knife for trimming the cable ties.

Procedure

1. Secure Mini Motion actuator in place, as shown below, onto the desired equipment using the two clevis pins and hitch pin clips provided with the equipment. Ensure the motor/pump is above the cylinder barrel.
2. Route the electrical cable toward the hitch securing it away from pinch points with cable ties provided.

