



QUADIVATOR INC

Box 218, Portage La Prairie, MB R1N 3B5 Canada Web: www.quadivator.com
Phone: (866) 770-2169 Fax: (204) 239-4271 Email: mailbox@quadivator.com

Hilling Moldboards

- 1) Remove the shovels from the front four shank assemblies of the Quadivator.
- 2) Spread apart the center two shank assemblies.
- 3) Install the left moldboard by fastening it to the left front shank and the left center shank of the Quadivator in place of the shovels.
- 4) Install the right moldboard by fastening it to the right front shank and the right center shank of the Quadivator in place of the shovels.
- 5) Remove the center shank assembly from the back row.
- 6) Flip the harrows forward into their transport position.

Helpful hints:

- a) Plant your rows as straight as possible.
- b) Be sure to be fully lined up to your row with the Quadivator trailing straight behind, before you start hilling.
- c) For hilling smaller vegetables, it is best to travel at a slow speed to prevent the hill from covering the small plants.

