



QUADIVATOR INC

Box 218, Portage La Prairie, MB R1N 3C5 Canada Web: www.quadivator.com
Phone: (866) 770-2169 Fax: (204) 239-4271 Email: mailbox@quadivator.com

Barb Wire Dispenser

- 1) Remove the outside two shank assemblies from the back row of shanks.
- 2) Flip the harrows into the transport position.
- 3) Slide the wire dispensers over the ends of the back toolbar.
- 4) Tighten the jam nuts.
- 5) Place the spool of wire over the vertical support.
- 6) Slide the spool retaining washer over the vertical support.
- 7) Install the hairpin into the hole located at the top of the vertical support.

Helpful hints:

Be sure to use the spool retaining washer and cotter pin. This will keep the wire spool from jumping out of its position in rough conditions.

