



QUADIVATOR

Box 218, Portage La Prairie, MB R1N 3C5 Canada Web: www.quadivator.com
Phone: (866) 770-2169 Fax: (204) 239-4271 Email: mailbox@quadivator.com

Irrigation Plow

- 1) Remove all the shank assemblies from the Quadivator.
- 2) Remove the hitch pole from the Quadivator frame.
- 3) Install the coulter disc onto the plow with the bolt supplied. (Do not over tighten).
- 4) Slide the hitch pole through the first pocket of the plow into the front pocket of the Quadivator into the second pocket of the plow and finally into the back pocket of the Quadivator.
- 5) Secure the hitch pole of the Quadivator in place with the hitch bolt.
- 6) Tighten the jam nut on the first pocket of the plow.
- 7) Flip the harrows into the transport position.

Helpful hints:

- a) Roll out the hose or wire on the ground in the direction you want to bury it.
- b) Straddle the hose or wire with your tractor or ATV.
- c) Feed the hose or wire through the plow.
- d) Have someone step on the end of the hose or wire when you start your travel forward.
- e) Not recommended in areas with stones or heavy tree roots.

